

## Furniture Solutions: Modular Table Assembly

Model Numbers: MT3333, MT4533, MT6833

### Introduction

This document provides the Pitney Bowes service rep with the instructions for assembling the Calstone Modular Table.

### Kit Contents

Box Contents:		Leg Box Contents:	
Qty.	Part Description	Qty.	Part Description
01	Table Top	02	Side Frames c/w leg inserts and levelling glides
01	Front Apron (already installed)		
01	Back Panel		
14	7/16" Hex Bolt		
14	Lock Washers		
01	9/16" Wrench		

**NOTE:** Do not discard packaging material until all contents are located.

SV62654 Rev. A  
June 2011  
Page 1 of 2

In the U.S.A., for further information on Console Inserter related issues, call DMT Worldwide Technical Support at 866-877-3683. For Table Top Inserter information, call Global Mailing Systems (GMS) at 800-692-0003. In the EAME area, call European Technical Support at +44 3333 440076.

This document is a publication of Pitney Bowes. The use of this information by the recipient or others for purposes other than the repair, adjustment or operation of Pitney Bowes equipment may constitute an infringement of intellectual property rights of Pitney Bowes or others. Pitney Bowes assumes no responsibility for any such use of the information. Except as provided in writing, duly signed by an officer of Pitney Bowes, no license, either express or implied, under any Pitney Bowes or any third party's patent, copyright, or other intellectual property rights is granted by providing this information.

## 2 | Furniture Solutions: Modular Table Assembly

### Installation

#### To assemble the table:

1. Lay table top down on a clean, padded surface, underside facing up.
2. Locate left and right leg panels and align over pre-drilled nut holes in table top.
3. Install hex bolts into aligned holes in table top. Do not tighten.
4. Repeat for opposite leg.
5. To install the back panel, angle panel and locate at rear of unit, aligning over nut holes with table top. Back panel fits on the inside of each leg.
6. Install hex bolts into aligned holes in table top.
7. Install hex bolts into aligned holes on back panel to each Leg.
8. Install hex bolts into aligned holes on the front apron to each leg.
9. Tighten all bolts with wrench provided.
10. To adjust legs, loosen nut with wrench provided. Align with desired index mark, then tighten locking nut.
11. Flip table over and place in desired location.

