Heavy-Duty Modular Furniture

Packing Table Assembly

(D-9000, D-9001, D-9005)

Component Parts:

- 1 Table Top with Frame
- 2 Table Legs
- 16 5/16-18 x 3/4 Hex Screw
- 4 3/8-16 x 1-1/2 Sterm x 1-11/16 Base Glide

Packing Table Assembly:

- 1. Place table top on floor with channels facing up.
- 2. Press leg frame into table top frame so holes line up, as shown.
- 4. Secure leg frame with bolts supplied in plastic bag on table.
- 5. Repeat steps 2-4 for second leg assembly.

Table Height Adjustment:

- 1. Adjustable leg channel on each leg member telescopes out and is notched every inch to make adjustment easy.
- 2. To adjust, loosen bolt on leg member and raise adjustable leg to the desired height; secure bolt.
- 3. Turn table upright to operating position.

NOTE: If optional drawer or cabinet has been ordered, secure mounting frame BEFORE putting table in operating position.

4. Minor height adjustments can be made by using the screw-type leveller on each adjustable leg channel or by resetting the telescope leg.

